

I have X rear brakes, can I install these on a Moser or Strange Engineering rear end?

1982-1992 GM F-Body: If you have a 1982-1992 F-Body Camaro or Firebird, the stock 10 bolt rear disc brakes can be mounted with some modifications to the stock brake backing plates, see the .pdf attachment below for the schematic. This shows what is required to install 1982-1992 F-Body Camaro and Firebird 10 bolt rear disc brakes on a Moser (only) rear end. Factory rear drum brakes and 9 bolt rear disc brakes will not work on any aftermarket rear end. We do offer an aftermarket 11" rear drum brake kit that will work on our aftermarket rear ends. These drum brake kits are supplied with the correct stud pattern to match your vehicle. We also offer various aftermarket rear disc brake kits that can be mounted as well.

1959-1964 GM B-Body, 1955-1957 Chevy, 1978-1987 GM G-Body, 1971-1976 GM B-Body and 1982-1992 GM S-10 (2WD): Your factory rear brakes will not work on any aftermarket rear end. We do offer aftermarket 9.5" and 11" rear drum brake kits that will work on our aftermarket rear ends. These drum brake kits are supplied with the correct stud pattern to match your vehicle. Use the 9.5" kit if you have 14" rims and the 11" kit for 15" or larger rims. We also offer various aftermarket rear disc brake kits that can be mounted as well.

All Other Vehicles: Your factory rear brakes can be mounted on aftermarket rear ends. For the 1993-2002 GM F-Body and 2005+ Ford Mustang, see the .pdf instructions attached below.

Aftermarket Rear Brakes: For aftermarket rear disc brakes that you already own and want to install on to your new aftermarket rear end such as Wilwood, Baer, SSBC, etc. you will need to supply us with the brand and part number of the brake kit you want to install. We will also need to know the fitment they are designed for. This information is required so the housing ends installed on the rear end will match your brake kit. See the housing ends .pdf attachment below to view our housing ends application schematic. If you are not sure what housing ends your brake kit is designed to fit this schematic provides an easy visual reference with all dimensions.

<https://www.spohn.net/support/questions/209/>