



## Spohn Performance, Inc.

494 E Lincoln Ave Myerstown, PA 17067

1-888-365-6064 www.spohn.net

### **USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!**

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller or the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

### **Center Link Instructions – Part # DS1049**

**Caution:** Proper service and repair procedures are essential for safe and reliable installation of chassis parts, and require experience and tools specially designed for the purpose. Installation of these parts by persons other than qualified mechanics could result in an unsafe vehicle and/or personal injury.

#### **Before installing the new center link, observe the following conditions:**

1. Connect center link stud to steering linkage with the slotted nuts that are attached to the new center link studs. Torque to 45 foot pounds.
2. If inner tie rods ends are attached to center link with slotted nuts and cotter pins, reuse the slotted nuts and install cotter pins. Torque to 45 foot pounds.
3. If inner tie rod ends are attached to center link with nuts that are not slotted, discard old nuts and install the new metric lock nuts supplied with this kit. Torque to 45 foot pounds.