

Spohn Performance, Inc.
494 E Lincoln Ave Myerstown, PA 17067
1-888-365-6064 www.spohn.net

Part # D94-02-FEL – Front Sway Bar End Links – Stock Ride Height

1994-2001 Dodge Ram 4x4 1500
1994-2002 Dodge Ram 4x4 2500 & 3500

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller nor the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

1. Block the rear tires of the vehicle so that the vehicle is stable and can't roll.
2. Remove the front end links from the stock front sway bar and the frame mount. The end links and all hardware may be discarded.
3. **1994-1997:** Install the rod end into the sway bar. You will need to turn the rod end into the sway bar like you are threading in a bolt. You may need to clean the hole up in the sway bar by running a 1/2" drill through it or by using a die grinder. Turn the rod end in to the sway bar until it is completely bottomed out. Then, holding the rod end horizontal with an adjustable wrench turn on and fully tighten the 1/2" lock nut.
1998-2002: Install the rod end in to the frame mount. You will need to turn the rod end into the mount like you are threading in a bolt. Turn the rod end in to the mount until it is completely bottomed out. Then, holding the rod end horizontal with an adjustable wrench turn on and fully tighten the 1/2" lock nut. This works fine on trucks with or without the tapered frame holes. If you have tapered frame holes the rod end will self center and seat squarely when you fully tighten the nut.
4. Connect the other end using the polyurethane bushings just like the factory set up. Make hand tight only at this time.
5. Repeat on the other side of the vehicle.
6. With your suspension loaded and at ride height tighten the poly bushed end of both end links. You want to tighten them until you see the bushings starting to deform and then stop tightening.
7. Installation is complete.