

Spohn Performance, Inc.

494 E Lincoln Ave Myerstown, PA 17067

1-888-365-6064 www.spohn.net

Part #GMSUV-00-06-202 – Boxed Rear LCAs – Polyurethane Bushed 2000-2006 GM SUV: Suburban, Tahoe, Yukon, Avalanche, Escalade, H2

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller nor the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

1. Lift rear of vehicle and support by frame rails. DO NOT SUPPORT BY REAREND!
2. Use jack and place under rear axle to support but do not lift.
3. Remove both rear control arm bolts and nuts and remove control arm. The axle will shift slightly rearward. (Only swap one LCA at a time, do each side separately)
4. Install control arm using the jack to help position the rear axle properly. Make the bolts hand tight only at this time.
5. Lower vehicle to regular ride height and tighten all bolts to 72 ft/lbs.

Note: The poly bushings come pre-lubed. **DO NOT** use petroleum based grease on your poly bushings! Poly bushings must be lubricated with synthetic silicone based waterproof grease. These are the manufacturer's recommendations to prevent premature bushing wear, and will keep things "squeak-free". You can order this grease from Spohn Performance using our Part #902. Do not over grease the bushings! You only need a couple pumps of grease. Over greasing will cause the bushings to balloon from the hydraulic pressure inside of the sleeve and they will fail.