

**Spohn Performance, Inc.**  
494 E Lincoln Ave Myerstown, PA 17067  
1-888-365-6064    [www.spohn.net](http://www.spohn.net)

**Part # D94-02-SP1 – Extreme Duty Transfer Case Skid Plate**

**1994-2001 Dodge Ram 4x4 1500**  
**1994-2002 Dodge Ram 4x4 2500 & 3500**

**USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!**

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller nor the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

**INSTRUCTIONS**

1. Block the tires of the vehicle so that the vehicle is stable and can't roll.
2. Remove the factory transfer case skid plate and bolts using a 15mm socket.
3. Install the Spohn Performance Extreme Duty transfer case skid plate using the supplied flanged head bolts and a 15mm socket. The two shorter bolts go in the front two holes. Use the longer bolts for the remaining holes. Start all of the bolts loosely and after all bolts have been loosely snugged go around and tighten all of the bolts.
4. Installation is complete.

## Extreme Duty Transfer Case Installed

