

Spohn Performance, Inc.
494 E Lincoln Ave Myerstown, PA 17067
1-888-365-6064 www.spohn.net

Part # D94-02-SB-2WD – Front Steering Box Support Brace
1994-2001 Dodge Ram 4x2 1500 | 1994-2002 Dodge Ram 4x2 2500 & 3500

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller nor the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

1. Front Sway Bar Removal: The front sway bar will drop when the bolts are removed, so remove with caution. Hold on to or support the front sway bar and then remove the four (15mm head) mounting bolts that secure the sway bar bushings to the frame. Allow the sway bar to swing down and rest on the steering linkage.
2. Using a 1-5/16" socket remove the steering box sector shaft bolt and lock washer.
3. Using a 1-1/4" deep socket install the new silver zinc plated sector shaft nut and lock washer. Tighten to 180 ft./lbs.
4. Slide the steering box support brace into place, where the mounting feet are positioned in between the sway bar bushings and the frame. When the sway bar is moved into place the large diameter hole on the bearing plate will be approximately centered on the sector shaft nut.
5. Install (snug, not tight) the four supplied (15mm head) flanged head bolts to re-secure the sway bar and the steering brace to the frame, while allowing for the final mounting position to be fine tuned. The bracket is aligned when the sector shaft nut is centered in the hole. It may be necessary to loosen the sway bar end link bolts (15mm head) to ease the process.
6. Install the two bolts from the top and down through the small holes in the bearing mounting plate so that the threads are hanging through the plate.
7. Before installing the bearing assembly, apply some Never-Seize to the sector shaft to help assist future removal. Loosen the set screws in the bearing using a 1/8" Allen wrench. Install the bearing assembly over the sector shaft nut until the bearing block comes to rest on the support plate (noting that the bearing block may not be flat to the plate at this point). With the two bolts slid through the holes in the bearing block, install the lock washers and nuts. Snug them but do not tighten.
8. Tighten the four sway bar bushing mounting bolts (15mm head) to 40 ft./lbs.
9. Ensure you have free movement (rotation) of the steering box sector shaft nut. If it is not free moving undo the sway bar bushing mounting bolts and re-adjust.
10. Fully tighten the bearing mounting nuts (3/4" head).
11. Remove the set screws and apply Loctite. Install and tighten the set screws using a 1/8" Allen wrench. Check that the grease fitting is tight. Use a standard grease gun to apply grease to the bearing. Grease bearing at every oil change.

