

Spohn Performance, Inc.

494 E Lincoln Ave Myerstown, PA 17067

1-888-365-6064 www.spohn.net

Part# 923-Rear – Rear Sway Bar - 1982-2002 GM F-Body

USE OF THIS PRODUCT IS ACCEPTANCE OF SELLER'S DISCLAIMER OF WARRANTY!

By their very nature, competition components are constantly pushed to their limits. While our components are designed to withstand intense race conditions, it is impossible to control the quality of installation or the varying conditions in which they are used. It is for this reason that absolutely no warranty or guarantee is either written or implied. Neither the seller or the manufacturer will be liable for any loss, damage, or injury – direct or indirect – arising from the use of or inability to determine the use of any product. Before using, the user should determine the suitability of the product for its intended use, and the user shall assume all responsibility in connection therewith. Spohn Performance, Inc. makes no guarantee as to the legality for any specific class. Spohn Performance, Inc. makes no claims, nor does it intend its products to be used in street driven vehicles. Spohn Performance, Inc. reserves the right to make changes in design or add to or improve on their product without incurring any obligation to install the same on product previously manufactured. The Buyer agrees to indemnify and hold Spohn Performance, Inc. harmless from any claim, action or demand arising out of or incident to the Buyer's installation or use of products purchased from Spohn Performance, Inc.

INSTRUCTIONS

1. Raise the rear of the car to an adequate working height, then support the chassis securely with jack stands. Support the differential with a floor jack so the rear axle housing can be raised/lowered if needed. The installation can be performed without removing the rear wheels.
2. Look carefully at the current installation of the rear sway bar and note the bar's properly installed orientation, etc.
3. Remove both of the rear sway bar end links from each end of the rear sway bar. These can be discarded.
4. Loosen all four of the factory rear sway bar bushing u-bolt nuts (two per side) leaving them engaged by a few threads to support the rear sway bar.
5. Support and/or hold the rear sway bar while removing the four rear sway bar bushing u-bolt nuts and then remove the rear sway bar from the car.
6. Grease the inside bore of both of the supplied polyurethane rear sway bar bushings using the supplied packets of Silicone® grease.
7. Install the polyurethane bushings onto our rear sway bar. Orient the bushings so that the bushing's split seam will face the front of the vehicle when installed. Then install the supplied rear sway bar bushing metal shells over the polyurethane bushings.
8. Hold our rear sway bar up into place and loosely install the bushings onto the u-bolts re-using the four factory u-bolt nuts and washers. Make the nuts lightly snug, do not fully tighten the nuts.
9. Loosely install the supplied polyurethane rear sway bar end links to both ends of our rear sway bar. Then loosely install the other end of both of the rear end links to the rear upper chassis mounts. Do not fully tighten.
10. Rotate the rear sway bar u-bolts and mounting saddles so they are centered on the bottom center line of the rear axle tube and then fully tighten all four of the rear sway bar bushing u-bolt nuts. **Do not over tighten the nuts**, you should be able to forcibly rotate the rear sway bar in the bushings by hand. Over tightening the u-bolt nuts will prevent the rear sway bar from rotating inside of the bushings, limiting suspension travel.
11. Safely lower the car to the ground.
12. With the car on the ground and the suspension loaded, using a 9/16" wrench, tighten the 3/8" Nylock® nut on the top of both of the rear sway bar end links. Tighten the nuts until you see the bushings starting to deform, then STOP.
13. Grease the bushings through their grease fittings using a synthetic Silicone® based grease. Do NOT ever use a petroleum based grease on polyurethane bushings. This grease is available from Spohn Performance – Part# 902.
14. Installation is complete.