

## **Spohn Performance | Support Center**

### **I'm missing the bushing clam shells for my front sway bar - SKU# 923-Front, 924-Front and 925GFront**

The poly bushings we supply with our SKU# 923-Front, 924-Front and 925GFront front sway bars are designed to mount inside of the stock bushing shells. You will simply remove your OEM rubber bushings from the stock shells and replace them with the supplied polyurethane bushings, they are a direct fit to the factory clam shells.

<https://www.spohn.net/support/questions/200/>