

**I'm ordering a rear end for a 1982-2002 F-Body Camaro Firebird, do I need the sway bar installation kit?**

If you are ordering a Moser Engineering rear end for your 1982-2002 F-Body Camaro and Firebird we ask if you want a sway bar installation kit. The sway bar installation kit provides all of the hardware required to mount a rear sway bar on to the new moser rear end. The factory hardware is too small to fit on the larger rear end.

Our rear sway bar mounting kit includes the larger saddles, u-bolts and end links that are needed. Our kit also spaces the sway bar down so it clears the larger torque arm mount on a Ford 9" rear end and the larger rear cover on a 12 bolt rear end. Because we space it down we include longer sway bar end links to keep the geometry correct.

Strange Engineering rear ends for the 1982-2002 F-Body Camaro and Firebird include the sway bar mounting kit so you do not need to order one if you are getting a Strange rear end.

<https://www.spohn.net/support/questions/259/>