

Do I need to remove my carpet when welding in your subframe connectors for the 1982-1992 and 1993-2002 F-Body Camaro & Firebird?

Our subframe connectors for the 1993-2002 F-Body Camaro and Firebird do not require any carpet lifting or removal. The subframe connectors weld to points that will not transfer any heat to the actual floor pan underneath the carpeting.

Our subframe connectors for the 1982-1992 F-Body Camaro and Firebird require you to lift the carpet, but there is no need for complete removal of the carpeting. You can simply remove the rocker panel cover and then slide a 2x4 underneath the carpet to hold it away from the floor pan at the weld points.

<https://www.spohn.net/support/questions/313/>