

I'm doing a LSx engine swap in to my 1982-1992 F-Body Camaro Firebird, what parts will I need?

To install a LSx engine in to a 1982-1992 GM F-Body (Camaro / Firebird) you will need the following components:

Mandatory:

1. Part #971 motor mount bushing adapter stands.
2. You must use 1998-2002 GM F-Body LS1 motor mount bushings with our adapter stands. If you do not already have these they are available from Spohn Performance, Part #GM-LSXMTRMT, and mounting hardware Part #970.
3. Transmission crossmember for a 1998-2002 GM F-Body 4L60E or T-56 transmission. We also have transmission crossmembers for various other transmissions as well, to see the full selection click [here](#).
4. LSx swap headers ([click here](#)).

Optional:

These items are not "required" but can further enhance your swap and it's performance. We offer various transmission crossmember/adjustable torque arm kits as well as various LSx swap tubular k-members for stock style steering or Pinto manual rack. To see the full line up of LSx swap parts click [here](#).

<https://www.spohn.net/support/questions/32/>